

**8** Gently lower the panel onto a clean, flat surface.

Lower the side of the computer onto a soft clean cloth to avoid scratching the case.

